

LITE TRACKER
The Personal Safety Light



MODEL G
Green Lens with
3 amber LEDs.
Flash only.



MODEL G1
Red Lens with
3 red LEDs.
Flash only.



MODEL G2
White Lens with
2 green LEDs.
Flash only.



MODEL G3
White Lens with
2 blue LEDs.
Flash only.

LITE TRACKER



MODEL 2016
Water Activated.
MODEL 2016A
Water Activated Coast
Guard Compliant.
Green Lens. 3 amber
LEDs in flashing pattern.


MODEL 2017
Push Button Activated.
MODEL 2017A
Push Button Activated
Coast Guard Compliant.
Green Lens. 3 amber
LEDs in flashing pattern.



GRACE
INDUSTRIES, INC.
Solutions for Life Safety

1-800-969-6933
724.962.9231
www.graceindustries.com

LITE TRACKER
The Personal Safety Light




♦ FIRE & RESCUE ♦ MARINE
♦ PUBLIC SAFETY ♦ INDUSTRY
♦ UTILITIES ♦ MILITARY

A bright flashing visual indicator that allows instant recognition of personnel. Utilizes a proprietary light multiplying principle that offers high visibility from all directions at a distance of up to one mile. Small, light weight Easily attaches to clothing. Made of tough industrial grade plastic. This durable material possesses excellent strength and optical qualities. Water resistant and will provide many years of carefree service.


GRACE
INDUSTRIES, INC.
Solutions for Life Safety

LITE TRACKER®

Individually Tested before leaving the factory results in a reliable line of safety lights.



A.



LITE TRACKER®

The Personal Safety Light



MODEL 2006
All American Alternating Pattern White Lens. Press button to turn the unit on. Red, white and blue LEDs start an alternating pulse pattern.



MODEL 2009 Amber Glow, Flash and Strobe
Green Lens. First button press-all 3 amber LEDs glow, press and hold-all 3 amber LEDs flash, continuing to hold will cause all 3 amber LEDs to strobe.



MODEL 2012 Green Glow, Flash and Strobe White Lens. First button press-all 3 green LEDs glow, press and hold-all 3 green LEDs flash, continuing to hold will cause all 3 green LEDs to strobe.



MODEL 2008 Red Glow, Flash and Strobe Red Lens. First button press-all 3 red LEDs glow, press and hold-all 3 red LEDs flash, continuing to hold will cause all 3 red LEDs to strobe.



MODEL 2013 Blue Glow, Flash and Strobe White Lens. First button press-all 3 blue LEDs glow, press and hold-all 3 blue LEDs flash, continuing to hold will cause all 3 blue LEDs to strobe.